




**EN** City and Countryside Wooden Toy Train  
Assembly instruction

**FR** Chemin de fer en bois Ville et pays  
Notice de montage

















**ES** Ferrocarril de madera Ciudad y Campo  
Instrucciones de montaje


**DE** Holzeisenbahn Stadt und Land  
Aufbauanleitung

**IT** Ferrovia in legno Città e campagna  
Istruzioni di montaggio



Art. Nr. 11490

			
A × 1	B × 8	C × 1	D × 2
			
E × 1	F × 8	G × 1	H × 1
			
I × 1	J × 1	K × 1	L × 1
			
M × 1	N × 1	O × 1	P × 1



**ALEGLER OHG** small foot company  
Achimer Straße 7  
27755 Delmenhorst / Germany  
www.small-foot.de



**WARNING!** Adult assembly required. **ACHTUNG!** Aufbau nur durch einen Erwachsenen. **ATTENTION!** Assemblage par un adulte requis. **AVVERTENZA!** Richiesto assemblaggio da parte di un adulto. **ADVERTENCIA!** Se requiere ensamblaje por un adulto.