

Art. Nr. 12434

Cupcake Display Tray „tasty“

Assembly instruction

Cupcake Etagere „tasty“

Aufbauanleitung

Étagère à cupcakes „tasty“


Notice de montage

Etagere di cupcake „tasty“

Istruzioni di montaggio

Soporte para cupcakes „tasty“

Instrucciones de montaje



CAUTION:

The toy is to be assembled by an adult.



CAUTION:

Assemblage par un adulte requis.



WARNING:

CHOKING HAZARD

Small parts. Not for children under 3 years.






AVERTISSEMENT:


RISQUE DE SUFFOCATION

Présence de petits éléments. Ne convient pas aux enfants de moins de 3 ans.





A x 1



B x 1



C x 1



D x 1










a x 1




x 1



WARNING! Adult assembly required. | ACHTUNG! Aufbau nur durch einen Erwachsenen. | ATTENTION! Assemblage par un adulte requis. | AVVERTENZA! Richiesto assemblaggio da parte di un adulto. | ADVERTENCIA! Se requiere ensamblaje por un adulto.

| | | | |
|--|--|--|--|
|  <p>x 1</p> |  <p>x 1</p> |  <p>x 1</p> |  <p>x 1</p> |
|  <p>x 2</p> |  <p>x 2</p> |  <p>x 4</p> | |

1



2

