

Art. Nr. 12904

LCD colouring book with colouring templates Safari

Directions for use

LCD Malbuch mit Malvorlagen Safari

Gebrauchsanweisung

Livre de coloriage LCD avec motifs Safari



Notice d'utilisation

Album da colorare LCD con disegni modello Safari

Istruzioni per l'uso

Libro con dibujos para colorear LCD Safari

Instrucciones de uso



CAUTION:

The toy is to be assembled by an adult.



CAUTION:

Assemblage par un adulte requis.



WARNING:

CHOKING HAZARD

Small parts. Not for children under 3 years.





AVERTISSEMENT:


RISQUE DE SUFFOCATION

Présence de petits éléments. Ne convient pas aux enfants de moins de 3 ans.






x 1





x 1




x 15

1




WARNING! Adult assembly required. | ACHTUNG! Aufbau nur durch einen Erwachsenen. | ATTENTION! Assemblage par un adulte requis. | AVVERTENZA! Richiesto assemblaggio da parte di un adulto. | ADVERTENCIA! Se requiere ensamblaje por un adulto.


2






3a



3b



4



WARNING! Adult assembly required. | ACHTUNG! Aufbau nur durch einen Erwachsenen. | ATTENTION! Assemblage par un adulte requis.
AVVERTENZA! Richiesto assemblaggio da parte di un adulto. | ADVERTENCIA! Se requiere ensamblaje por un adulto.

