



































ASSEMBLY INSTRUCTION

MT-3422 LG

A  2x	B  2x	C  2x	D  2x	E  1x	F  1x	
G  1x	H  1x	I  1x	J  2x	K  1x	L  1x	M  1x
N  1x	O  1x	P  1x	Q  1x	R  1x	S1  4x	S2  4x
T1  2x	T2  2x	T3  2x	U  6x	V  1x	W1  1x	W2  1x
W4  1x	W5  1x	X1  ESK-52 8x	X2  QC 8x	X3  GR-19F 40x	X4  GI-40 2x	Y  FF 1x

ADULT ASSEMBLY