















Charlotte's Doll House











ASSEMBLY INSTRUCTION

Contents
54147

Please make sure to count all components before you begin assembling the product.

maxim[®]
enterprise inc

 A x1	 B x1
 C x1	 D x1
 E x2	 F x1
 G x1	 H x3
 I x3	 J x4
 K x3	 L x2
 M x16	 N x12



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

Adult Assembly Required

Maxim Enterprise, Inc. For customer service information please contact us toll free at: 1-888-26-MAXIM(266-2946) or visit our website at: www.maximenterprise.com

Made in China